

Instructions to install 2-3/4 barrel kit:

1. There are three dowel pins that need to be replaced. The dowel pins are circled in blue below. Remove the eclips that hold the dowel pins in place, pull the black dowel pin out, replace with the new, longer black pins, and put the same eclips back on. Be sure to leave one eclips off each pin until steps 2 and 3 are completed.
2. Each of the flat, profiled stainless steel shims go between the red side frame and the silver lower anvil. Remove the screws that are circled in yellow in the photo. Do this on both sides. Place one shim on each side of the anvil and then fasten the anvil back to the red frame.
3. The dowel pin shown on the far left also gets the 3/8 nylon bushing between the red frame and silver lever. One goes on each side to span the gap you created from the shims you installed.

